

Fitting Instructions for Stafford

1. Find centre of door opening and measure out position of canopy. Drill & fix temporary timber support batten.
2. Position bottom tray onto batten and centralise with the door opening, screw back against wall using screws and washers.
3. Slide top onto bottom tray and fix back to wall through the upstand at approximately 300mm intervals.
4. Remove temporary timber support batten.
5. Clean off any dust or dirt and seal using suitable silicone sealant.
6. Your installation is now completed.

Your canopy will give years of maintenance free service and requires only the occasional wash with warm soapy water.

NB Do not use abrasive or solvent cleaners on this product.