

Door Surround

Fitting Instructions as follows:

- 1) Cut pillars to required length, by reducing the height of the bottom box, using a fine tooth panel saw/hand saw.
- 2) Drill, screw and cap pillars with 3" screws at top and bottom.
- 3) Stand Georgian top on top of pillars. Drill and cap top of flange using 2" screws.
- 4) Silicone all around outside and inside edges using matching silicone.

(Fitting time 1-1 ½ hours approx)

You will need: - 2x tubes of silicone
4x 3" screws
4x 2" screws
8x screw caps