

Fitting Instructions

Victorian/Victorian Winged/Georgian/Edwardian Door Surrounds

1. Measure from top of door opening to ground level. Measure pillar and trim off excess at bottom of pillar to the same size.
2. Hold pillar against wall and fix top and bottom with 1x3" screw/plug/white cap at top of flat section and 1x4" screw/plug/cap, bottom flat section take care not to over tighten screws as this will distort the pillar, and cause cracking.
3. Place top section above door and centralize over the two pillars. Top can then be fixed by using 2" screws/plugs/caps along top flange at approximately 300mm spacings.
4. Clean off all dust and dirt using a soft cloth ensuring not to scratch the gelcoat surface. We also recommend sweeping up all dust on site ready for the next step.
5. Finish off by sealing around your new surround using silicone sealant of the appropriate colour.
6. Your surround will look good for many years. All that is necessary is to clean with warm soapy water and a soft cloth at regular intervals.

Items needed:

2 x 3" screws
2 x 4" screws
6 x 2" screws

10 x rawlplugs
10 x screw cover caps
2 x tubes silicon