

Victorian Portico Fitting Instructions

1. Place columns in correct position and draw around bottom edges.
2. Make 2x2 timber frame to fit inside of the column, position timber frame and screw down to the floor, sit the column over the timber frame.
3. Repeat the process at the top of the column, using a rounded piece of plywood or blockboard, screw this in position on the underside of the portico ceiling.
4. Place the portico on top of the columns so the blockboard drops inside the hole in the top of the column.
5. The portico top will need to be temporary supported against the wall with a batten or a prop until it has been securely fixed with plugs and screws, the temporary supports can then be removed.
6. Clean off any dust or dirt using soft cloth prior to sealing with silicon sealant where necessary.

**Electric cable can be fitted prior to portico top being fixed to the wall if light is to be installed on the ceiling.*